





FS001S Ski Stepper Ground Anchor Detail



Critical Note!
Care must be taken to ensure the equipment will face in the correct direction whilst installing the 'Fitness Range Ground Anchor' (955800). Please align the flange hole centers as illustrated.



FS002S Mini Ski Ground Anchor Detail




Grass mat

Critical Note!
Care must be taken to ensure the equipment will face in the correct direction whilst installing the 'Fitness Range Ground Anchor' (955800). Please align the flange hole centers as illustrated.

Fall space




FS003S Pull Down Challenger Ground Anchor Detail





FS004S Sit Up Ground Anchor Detail



Grass mat

Fall space


Center Line

Enlarged view of anchor flange detail for clarity

Critical Note!
Care must be taken to ensure the equipment will face in the correct direction whilst installing the 'Fitness Range Ground Anchor' (955800). Please align the flange hole centers as illustrated.




FS005S Health Walker Ground Anchor Details



Critical Note!
Care must be taken to ensure the equipment will face in the correct direction whilst installing the 'Fitness Range Ground Anchor' (955800). Please align the flange hole centers as illustrated.



FS007S Leg Stretch Ground Anchor Detail



Fall space

Grass mat

Center Line


Enlarged view of anchor flange detail for clarity

Critical Note!

Care must be taken to ensure the equipment will face in the correct direction whilst installing the 'Fitness Range Ground Anchor' (955800). Please align the flange hole centers as illustrated.




FS008S Power Push Ground Anchor Detail






FS009S Parallel Rail Ground Anchor Detail



Critical Note!
Care must be taken to ensure the equipment will face in the correct direction whilst installing the 'Fitness Range Ground Anchor' (955800). Please align the flange hole centers as illustrated.




FS010S Push Hands Ground Anchor Detail





FS011S Handle Boat Ground Anchor Detail



Grass mat

Critical Note!

Care must be taken to ensure the equipment will face in the correct direction whilst installing the 'Fitness Range Ground Anchor' (955800). Please align the flange hole centers as illustrated.

Fall space